




Using Handibot's Built In Dust Collection System


- 1 For safety, turn router power switch to "OFF" before putting your hands near the router.



- 2 To use dust collection, simply insert a 1.25" vacuum hose from your chosen vacuum into the port on the rear of your handibot.




- 3 For best results, adjust the position of the router in its bracket so that the end of your bit lines up with the end of the vacuum foot brushes.



- 4 To remove the vacuum foot entirely, unscrew the hose from the handibot by twisting it clockwise.



- 5 Once the vacuum foot is released, set it somewhere out of the way so that the tool doesn't roll over it during cutting.



6 Turn router power switch back to "ON" to get ready to start cutting!

